


ADG-410



Parts Manual

1995 thru 1998

American Dryer Corporation

88 Currant Road Fall River, MA 02720-4781

Telephone: (508) 678-9010 / Fax: (508) 678-9447

E-mail: techsupport@amdry.com

082896

021898WL/tf ADC Part No. 450166

Retain This Manual In A Safe Place For Future Reference

American Dryer Corporation products embody advanced concepts in engineering, design, and safety. If this product is properly maintained, it will provide many years of safe, efficient, and trouble-free operation.

ONLY properly licensed technicians should service this equipment.

OBSERVE ALL SAFETY PRECAUTIONS displayed on the equipment or specified in the installation/operator's manual included with the dryer.

WARNING: <u>UNDER NO CIRCUMSTANCES</u> should the door switch or the heat circuit devices ever be disabled.

WARNING: The dryer *must never* be operated with any of the back guards, outer tops, or service panels removed. PERSONAL INJURY or FIRE COULD RESULT.

We have tried to make this manual as complete as possible and hope you will find it useful. **ADC** reserves the right to make changes from time to time, without notice or obligation, in prices, specifications, colors, and material, and to change or discontinue models.

Important

For your convenience, log the following information:

DATE OF PURCHASI	E	MODEL NO.	ADG-410
DISTRIBUTORS NAM	ЛЕ		
Serial Number(s)			

Replacement parts can be obtained from your distributor or the **ADC** factory. When ordering replacement parts from the factory, you can FAX your order to **ADC** at (508) 678-9447 or telephone your orders directly to the **ADC** Parts Department at (508) 678-9010. Please specify the dryer **model number** and **serial number** in addition to the **description** and **part number**, so that your order is processed accurately and promptly.


The illustrations on the following pages may not depict your particular dryer exactly. The illustrations are a composite of the various dryer models. Be sure to check the descriptions of the parts thoroughly before ordering.

INSTRUCTIONS TO BE FOLLOWED IN THE EVENT THE USER SMELLS GAS MUST BE POSTED IN A PROMINENT LOCATION. THE INSTRUCTIONS TO BE POSTED SHALL BE OBTAINED FROM THE LOCAL GAS SUPPLIER.

Table of Contents

Front Panel Assembly, Automatic Door	
Solid Back Panel Assembly	4
Automatic Door Pneumatics Assembly	5
Left Automatic Load Door Assembly	
Right Automatic Load Door Assembly	8, 9
Right Front Control Door Assembly	0, 11
Left Control Door Assembly	12
Lint Basket Assembly	13
Base Solenoid Junction Box Assembly 1	4, 15
Sprinkler Option Control Panel Assembly 1	6, 17
Right Hand Electrical Panel Wireway Channels 1	8, 19
Top of Right Hand Electrical Panel	
For models mfd. as of August 26, 1997	20, 21
Top of Right Hand Electrical Panel	
For models mfd. prior to August 26, 1997	22, 23
Bottom of Right Hand Electrical Panel	24, 25
All Door, All Tilt, Base Electrical Junction Box Control Panel Assembly 2	26, 27
Drive Motor Assembly	
For models mfd. as of November 14, 1997	28
Drive Motor Assembly	
For models mfd. prior to November 14, 1997	29
Drive Shaft Assembly	
For models mfd. as of November 14, 1997	30
Drive Shaft Assembly	
For models mfd. prior to November 14, 1997	31
Speed Reducing Idler Shaft Assembly	
For models mfd. prior to November 14, 1997	32, 33
Tumbler and Idler Shaft Assembly	
Rotational Sensor Assembly Diagram	
Fan Motor Assembly	
Temperature Sensor Bracket	38
DSI Module Assembly	39
Front Burner Box Assembly 4	0, 41
Rear Burner Box Assembly 4	2, 43
Sail Switch Assembly	
Air Jet Assembly	
Gas Piping Assembly	
Tilt Switch Assembly	49
Tilt Piston Mount Assembly	50
Post Assembly	51
Pneumatic Assembly	
For 1 Automatic Door	52
Pneumatic Assembly	
For 2 Automatic Doors	53
Pneumatic Panel Assembly	
For One-Way Tilt Models	4, 55
Pneumatic Panel Assembly	
For Two-Way Tilt Models 5	
Optional Sprinkler Assembly 5	
Sprinkler Temperature Probe Junction Box Assembly	
Steam Coil Assembly	2, 63
Sprinkler Solenoid Assembly	
Tumbler Retaining Wheel Mount Assembly	65
Guard Assemblies	
For Two-Way Tilt Models 6	
Side Panel Assemblies	
Front Base & Front Top Panel Assemblies	
End of Cycle Light Assembly	
Selector Switch. Nameplate, and Mounting Base Chart	72

NOTE: Same assembly used as Rear Panel assembly for Two-Door Models.




NOTE: Same assembly used as Rear Panel assembly for Two-Door Models.

Illus. No.	Part No.	<u>Qty</u>	Description
1*	814059	1	Upper Guard
2*	814058	1	Middle Guard
3*	881388	1	Left Control Cabinet
4*	881387	1	Right Control Cabinet
5	150510	6	1/4-20 x 3/4" Hex Head Machine Bolt
6	153007	6	1/4" Lock Washer
7	153018	6	1/4" Flat Washer
8	153001	10	5/16" Flat Washer
9	153002	10	5/16" Lock Washer
10	150501	10	5/16-18 x 3/4" Hex Head Machine Bolt
11*	814057	1	Bottom Guard
12	332938	1	Feed Through Plate
13	150309	4	Crimptite Screw
14	881386	1	Front Panel Assembly
15		4	Retaining Wheel Assembly (see page 65)
16	814070	2	Retaining Wheel Cover
17	153018	4	1/4" Flat Washer
18	150309	4	Crimptite Screw
19	150523	10	1/4-20 x 3/4" Hex Washer Head Machine Bolt
20	170362	2	Bottom Door Track
21	154312	14	#10-32 x 3/4" Socket Head Cap Screw
22	170363	1	Upper Door Track
23	154312	16	#10-32 x 3/4" Socket Head Cap Screw
24	821452	4	Door Switch Assembly
25	153004	12	3/8" Flat Washer
26	153005	12	3/8" Lock Washer
27	150617	12	3/8-16 x 1" Hex Head Bolt
28	150605	4	1/2-13 x 1-1/2" Hex Head Bolt
29	153026	4	1/2" Lock Washer
30	153050	8	1/2 x 1/16 Flat Washer
31	152011	4	1/2-13 Hex Nut
32	116009	1	200" x 1-3/8" Felt Tumbler


^{*} Specify color when ordering

NOTE: For 1 Door Models




Illus. No.	Part No.	Qty	<u>Description</u>
1*	334615	1	Solid Back Panel Top Cover
2	150522	26	1/4-20 x 1/2" TEK Screw
3*	334616	1	Solid Back Panel Bottom Cover
4	150522	26	1/4-20 x 1/2" TEK Screw
5	170344	4	Nylon Back Guide
6	150311	12	#10 x 3/4" Hex Head Crimptite Screw
7*	334542	2	Piston Cover
8	150309	12	#10-16 x 1/2" Hex Head Crimptite Screw
9*	334541	1	Rear Left Base Panel
10	150522	6	1/4-20 x 1/2" TEK Screw
11*	814069	1	Transition Piece (One Door Dryer ONLY)
12	150522	6	1/4-20 x 1/2" TEK Screw
13	150617	12	3/8-16 x 1" Hex Head Bolt
14	153005	12	3/8" Lock Washer
15	153004	12	3/8" Flat Washer
16	150522	12	1/4-20x 1/2" TEK Screw
17*	334521	2	Solid Back Panel Wheel Cover
18*	334520	1	Solid Back Panel Center Cover
19	150522	14	1/4-20 x 1/2" TEK Screw

^{*} Specify color when ordering




Illus. No.	Part No.	<u>Qty</u>	Description
1	150308	8	#8-32 x 2-1/2" Long Machine Screw
_		_	č
2	153000	8	#8 Flat Washer
3	100432	2	Cable Cylinder
4	128978	4	1/8" NPT x 1/4" Tube Flow Control
5	143156	2	1/4" Poly Tee
6	143154	2	1/4" Brass Poly Connector
7	143110	A/R	1/4" Poly Flo Tubing (sold by the foot)
8	153012	4	#8 Star Washer
9	152001	4	#8-32 Hex Nut
10	150103	4	#8-32 x 3/4" Phillips Head Machine Screw
11	153000	8	#8 Flat Washer
12	153012	8	#8 Star Washer
13	152001	8	#8-32 Hex Nut

A/R - As Required




Illus. No.	Part No.	<u>Qty</u>	<u>Description</u>
1*	881392	1	Left Automatic Load Door Assembly Complete (includes illus. nos. 1-11)
	881391	1	Left Automatic Load Door ONLY
2	150112	3	1/4-20 x 1-1/4" Hex Head Machine Screw
3	153018	3	1/4" Flat Washer
4	153007	3	1/4" Lock Washer
5	152002	3	1/4-20 Hex Nut
6	102102	1	Magnet
7	154200	1	5/32" Pop Rivet
8	170367	2	Stainless Steel Stationary Bushing
9	170366	2	Stainless Steel Sealed Wheel
10	115995	80"	Felt Gasket (sold by the inch)
11	334134	1	Automatic Door Bracket
12	152002	2	1/4-20 Hex Nut
13	153007	2	1/4" Lock Washer
14	170366	2	Stainless Steel Sealed Wheel
15	170367	2	Stainless Steel Stationary Bushing
16*	334558	1	Lower Trolley ONLY
17	150301	3	#8-18 x 7/16" Hex Head Machine Screw
18	150112	2	1/4-20 x 1-1/4" Hex Head Machine Screw
19	153018	2	1/4" Flat Washer

^{*} Specify color when ordering



Illus. No.	Part No.	<u>Qty</u>	Description
1*	881390	1	Right Automatic Load Door Assembly Complete (includes illus. nos. 1-12)
	881389	1	Right Automatic Load Door ONLY
2	150112	3	1/4-20 x 1-1/4" Hex Head Machine Screw
3	153018	3	1/4" Flat Washer
4	153007	3	1/4" Lock Washer
5	334134	1	Automatic Door Bracket
6	152002	3	1/4-20 Hex Nut
7	102102	1	Magnet
8	154200	1	5/32" Pop Rivet
9	170367	2	Stainless Steel Stationary Bushing
10	170366	2	Stainless Steel Sealed Wheel
11	115995	80"	Felt Gasket (sold by the inch)
12	102215	1	Glass Window
	170730	1	Glass Adhesive (10.3 oz. Cartridge)
13	152002	2	1/4-20 Hex Nut
14	153007	2	1/4" Lock Washer
15	170366	2	Stainless Steel Sealed Wheel
16	170367	2	Stainless Steel Stationary Bushing
17*	334558	1	Lower Trolley ONLY
18	150301	3	#8-18 x 7/16" Hex Head Machine Screw
19	150112	2	1/4-20 x 1-1/4" Hex Head Machine Screw
20	153018	2	1/4" Flat Washer

^{*} Specify color when ordering




Illus. No.	Part No.	Qty	Description
1	122351	1	Large "EMERGENCY STOP" (Mushroom Head) Button
2	122419	1	"EMERGENCY STOP" Nameplate
3*	122360	1	2-Position Selector Switch
4*	122413	1	"TILT OFF - TILT ON" Nameplate
5	123201	1	Green "CONTROL VOLTAGE ON" Button
6	122410	1	Power "ON" Nameplate
7	123212	1	Incandescent Bulb - 24 VAC
8	123204	1	Red "CONTROL VOLTAGE OFF" Button
9	122421	1	Power "OFF" Nameplate
10**	123200	1	Amber "Push Button" Lighted Operator
11**	122420	1	Engraved "SPRINKLER STOP" Nameplate
12**	123211	1	120 VAC Incandescent Bulb

Illus. No.	Part No.	<u>Qty</u>	Description
13		_	Selector Switch
13			(refer to Selector Switch, Nameplate, and Mounting Base Chart on page 71)
14		_	Nameplate
			(refer to Selector Switch, Nameplate, and Mounting Base Chart on page 71)
15	123202	1	White "Push Button" Operator
16	122416	1	"REVERSE" Nameplate
17	123203	1	Black "Push Button" Operator
18	122415	1	"FORWARD" Nameplate
19	160140	1	ACE® XX4451 Key ONLY
20	160050	1	ACE® Control Door Lock ONLY less Key (keyed to #XX4451)
21	112535	1	OPL English Keyboard Label Assembly
	112276	1	OPL Stick-On Labels (English ONLY) Not Illustrated
	112275	1	OPL Stick-On Labels
			(Spanish, Italian, and Hebrew ONLY) Not Illustrated
	112277	1	3-Language OPL Stick-On Labels
			(English, Spanish, and Hebrew ONLY) Not Illustrated
	112278	1	5-Language OPL Stick-On Labels
			(Italian, Dutch, French, German, and Chinese ONLY) Not Illustrated
22***		1	Right Hand Control Door Assembly
			(contact factory with dryer serial number)
23	160014	1	Cam ONLY
24	150005	2	#6-32 x 1/4" Phillips Round Head Machine Screw
25	153010	2	#6 Star Washer
26	881129	1	Phase 5 OPL Reversing Microprocessor with External PLC Interface
	137227	1	Phase 5 OPL Reversing Microprocessor with Interface Connector
27	132396	1	Mounting Base with 1 N.O. and 1 N.C. Contact Block
28	132396	1	Mounting Base with 1 N.O. and 1 N.C. Contact Block
29	132394	1	Mounting Base with 1 Normally Open (N.O.) Contact Block
30	132395	1	Mounting Base with 1 Normally Closed (N.C.) Contact Block
31	132387	1	Normally Closed (N.C.) Contact Block
32	132388	1	Normally Open (N.O.) Contact Block with Direct Supply Base
33	132395	1	Mounting Base with 1 Normally Closed (N.C.) Contact Block
34**	132388	1	Normally Open (N.O.) Contact Block with Direct Supply Base
35	121509	3	Metal Clip-On Mount
36	122424	1	Power Warning Label "Small Triangle"
37		-	Mounting Base
20			(refer to Selector Switch, Nameplate, and Mounting Base Chart on page 71)
38		-	Mounting Base
20	112007	1	(refer to Selector Switch, Nameplate, and Mounting Base Chart on page 71)
39	112905	1	"Phase 5 Computer System" Label
40	112534	1	"Phase 5 Computer Location" Label

^{*} For 2-Way Tilt models ONLY


^{**} For models with the Sprinkler Option

^{***} Specify color when ordering




Illus. No.	Part No.	Qty	Description
1 2	160140 160050	1 1	Key ONLY for Control Door Lock (#XX4451) Control Door Lock Less Key (Keyed to #XX4451)
3	160014	1	Cam
4	112360	1	ADC Logo
5*	821334	1	Left Hand Control Door ONLY

^{*} Specify color when ordering



Illus. No.	Part No.	Qty	Description
1*	881393	1	Lint Drawer Assembly Complete (includes illus nos. 1 and 2)
2	117602	7	Noise Suppressor Tape (sold by the foot)
3	814036	1	Lint Screen
4	122116	1	Lint Drawer Switch ONLY
5	122605	2	4-Pin Socket Connector ONLY
6	122701	4	Socket Terminal ONLY
	122801	1	Pin/Socket Extraction Tool (NOT ILLUSTRATED)
7	800264	1	Lint Drawer Switch Box Assembly Complete
			(includes illus. nos. 4 through 7)
	304034	1	Lint Drawer Switch Box ONLY
8	150301	4	#8-18 x 7/16" Phillips Pan Head TEK Screw
9	122700	4	Pin Terminal ONLY
10	122604	2	4-Pin Connector ONLY
11	150301	2	#8-18 x 7/16" Phillips Pan Head TEK Screw


^{*} Specify color when ordering




<u>Illus. No.</u>	Part No.	<u>Qty</u>	<u>Description</u>
1	120651	2	1/2" N.P.T. 90° Cord Grip (Blue)
2	120650	2	1/2" N.P.T. 90° Cord Grip (White)
3	120914	4	1/2" N.P.T. Metal Clad Sealing Washer
4	120915	4	1/2" N.P.T. Lock Nut
5	120650	2	1/2" N.P.T. 90° Cord Grip (White)
6	120651	2	1/2" N.P.T. 90° Cord Grip (Blue)
7	120914	4	1/2" N.P.T. Metal Clad Sealing Washer
8	120915	4	1/2" N.P.T. Lock Nut
9*	121107	1	Junction Box
10	120111	1	1/2" Liquid Tite 45° Fitting
11	120657	1	3/4" N.P.T. 45° Cord Grip (Yellow)
12	120768	9	DIN Mounting Rail (Sold by the inch)
13	150309	4	#10-16 x 1/2" Hex Head Crimptite Screw
14	120765	1	End Stop
15	120766	1	End Plate
16	120758	24	Feed Through Terminal Block
17	120761	1	Four Position Feed Through Terminal Block
18	120991	1	Four Pole Bus Bar
19	120752	4	Terminal Block with Test Point
20	120999	7	Blank Marking Tag
21	120998	4	Bus Bar Screw
22	120750	4	Ground Terminal Block
23	122425	1	Triangle Warning Label
24	332847	1	Base Solenoid Junction Box Panel ONLY

^{*} Due to the various options, Box is shipped Blank (with no holes). Approximate holes **must be** drilled in the field.

Telephone: (508) 678-9010 Fax: (508) 678-9447



1	Illus. No.	Part No.	<u>Qty</u>	Description
136057	1	120750	1	Ground Terminal Block
3	2	136050	1	1 Amp Slo-Blo Fuse (for 208/240 volt models)
1		136057	1	1/2 Amp Slo-Blo Fuse (for 380-460 volt models)
5 136057 1 12 Amp Slo-Blo Fuse (for 208/240 volt models) 6 120756 1 1/4 Fuse Terminal Block with L.E.D. 7 120761 2 Four Position Feed Through Terminal Block 8 136033 1 3 Amp Fuse 9 120756 1 1/4" Fuse Terminal Block with L.E.D. 10 120761 2 Four Position Feed Through Terminal Block 11 136039 1 1/4 Amp 5 x 20mm Fuse 12 120754 1 5 x 20mm Fuse 12 120766 1 End Section 13 120765 1 Standard End Stop 15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 416 volt models) 132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer <tr< td=""><td>3</td><td>120999</td><td>5</td><td>Blank Marking Tag</td></tr<>	3	120999	5	Blank Marking Tag
136057	4	120756	1	1/4" Fuse Terminal Block with L.E.D.
6 120756 1 1/4" Fuse Terminal Block with L.E.D. 7 120761 2 Four Position Feed Through Terminal Block 8 136033 1 3 mp Fuse 9 120756 1 1/4" Fuse Terminal Block with L.E.D. 10 120761 2 Four Position Feed Through Terminal Block 11 136039 1 1/4 Amp 5 x 20mm Fuse 12 120754 1 5 x 20mm Fuse Terminal Block with L.E.D. 13 120766 1 End Section 14 120765 1 Standard End Stop 15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 380 volt models) 132078 1 Control Transformer (for 460 volt models) 132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer	5	136050	1	1 Amp Slo-Blo Fuse (for 208/240 volt models)
7 120761 2 Four Position Feed Through Terminal Block 8 136033 1 3 Amp Fuse 9 120761 2 Four Position Feed Through Terminal Block 10 120761 2 Four Position Feed Through Terminal Block 11 136039 1 1/4 Amp 5 x 20mm Fuse 12 120754 1 5 x 20mm Fuse Terminal Block with L.E.D. 13 120766 1 End Section 14 120765 1 Standard End Stop 15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 380 volt models) 132093 1 Control Transformer (for 416 volt models) 132076 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw		136057	1	1/2 Amp Slo-Blo Fuse (for 380-460 volt models)
8 136033 1 3 Amp Fuse 9 120756 1 1/4" Fuse Terminal Block with L.E.D. 10 120761 2 Four Position Feed Through Terminal Block 11 136039 1 1/4 Amp 5 x 20mm Fuse 12 120754 1 5 x 20mm Fuse Terminal Block with L.E.D. 13 120766 1 End Section 14 120765 1 Standard End Stop 15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #I0 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 460 volt models) 132093 1 Control Transformer (for 460 volt models) 132094 1 Control Transformer (for 460 volt models) 132095 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 20 131408 2 DPDT Relay 21 13140	6	120756	1	1/4" Fuse Terminal Block with L.E.D.
9	7	120761	2	Four Position Feed Through Terminal Block
10	8	136033	1	3 Amp Fuse
11 136039 1 1/4 Amp 5 x 20mm Fuse 12 120754 1 5 x 20mm Fuse Terminal Block with L.E.D. 13 120766 1 End Section 14 120765 1 Standard End Stop 15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 380 volt models) 132006 1 Control Transformer (for 460 volt models) 132078 1 Control Transformer (for 460 volt models) 132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Relay 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103	9	120756	1	1/4" Fuse Terminal Block with L.E.D.
12 120754 1 5 x 20mm Fuse Terminal Block with L.E.D. 13 120766 1 End Section 14 120765 1 Standard End Stop 15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 380 volt models) 132006 1 Control Transformer (for 460 volt models) 132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Relay 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25	10	120761	2	Four Position Feed Through Terminal Block
13 120766 1 End Section 14 120765 1 Standard End Stop 15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 208/240 volt models) 132093 1 Control Transformer (for 208/240 volt models) 132094 1 Control Transformer (for 460 volt models) 132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Relay 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153005<	11	136039	1	1/4 Amp 5 x 20mm Fuse
14 120765 1 Standard End Stop 15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 380 volt models) 132006 1 Control Transformer (for 416 volt models) 132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Relay 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005	12	120754	1	5 x 20mm Fuse Terminal Block with L.E.D.
15 120768 6 DIN Mounting Rail (Sold by the inch) 16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 380 volt models) 132006 1 Control Transformer (for 416 volt models) 132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Socket 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8" Lock Washer 28 121429	13	120766	1	End Section
16 150300 6 #10 x 1/2" Long Self Drilling Screw 17 132091 1 Control Transformer (for 208/240 volt models) 132092 1 Control Transformer (for 380 volt models) 132006 1 Control Transformer (for 416 volt models) 132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Socket 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 30 120768	14	120765	1	Standard End Stop
132091	15	120768	6	DIN Mounting Rail (Sold by the inch)
132092	16	150300	6	#10 x 1/2" Long Self Drilling Screw
132006	17	132091	1	Control Transformer (for 208/240 volt models)
132078 1 Control Transformer (for 460 volt models) 18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Socket 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 Four Position Feed Through Terminal Block 34 120		132092	1	Control Transformer (for 380 volt models)
18 153000 4 #8 Flat Washer 19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Socket 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 I" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 Four Position Feed Through Terminal Block 34 120751 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 </td <td></td> <td>132006</td> <td>1</td> <td>Control Transformer (for 416 volt models)</td>		132006	1	Control Transformer (for 416 volt models)
19 150108 4 8-32 x 1/2" Slotted Head Machine Screw 20 131408 2 DPDT Socket 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Hock Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 I" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 <td></td> <td>132078</td> <td>1</td> <td>Control Transformer (for 460 volt models)</td>		132078	1	Control Transformer (for 460 volt models)
20 131408 2 DPDT Socket 21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 I' Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 2 Four Position Feed Through Terminal Block 37 120758	18	153000	4	#8 Flat Washer
21 131405 2 DPDT Relay 22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 39	19	150108	4	8-32 x 1/2" Slotted Head Machine Screw
22 131409 2 Hold Down Wires for P/N: 131405 23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 4	20	131408	2	DPDT Socket
23 150103 3 8-32 x 3/4" Slotted Head Machine Screw 24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 <td>21</td> <td>131405</td> <td>2</td> <td>DPDT Relay</td>	21	131405	2	DPDT Relay
24 122424 1 Power Warning Label 25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108	22	131409	2	Hold Down Wires for P/N: 131405
25 153004 4 3/8" Flat Washer 26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	23	150103	3	8-32 x 3/4" Slotted Head Machine Screw
26 153005 4 3/8" Lock Washer 27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw <td>24</td> <td>122424</td> <td>1</td> <td>· · · · · · · · · · · · · · · · · · ·</td>	24	122424	1	· · · · · · · · · · · · · · · · · · ·
27 152005 4 3/8-16 Hex Nut 28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	25	153004	4	3/8" Flat Washer
28 121429 36 Slotted Wall Wire Duct (Sold by the inch) 29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	26	153005	4	3/8" Lock Washer
29 121422 36 1" Wireway Cover (Sold by the inch) 30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	27	152005	4	3/8-16 Hex Nut
30 120768 6 DIN Mounting Rail (Sold by the inch) 31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	28	121429	36	Slotted Wall Wire Duct (Sold by the inch)
31 120765 1 Standard End Stop 32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	29	121422	36	1" Wireway Cover (Sold by the inch)
32 120766 1 End Section 33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	30	120768	6	DIN Mounting Rail (Sold by the inch)
33 120750 1 Ground Terminal Block 34 120761 1 Four Position Feed Through Terminal Block 35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw		120765	1	•
341207611Four Position Feed Through Terminal Block351207582Feed Through Terminal Block361207611Four Position Feed Through Terminal Block371207585Feed Through Terminal Block381207612Four Position Feed Through Terminal Block391207651Standard End Stop403330021Sprinkler Mounting Bracket411530002#8 Flat Washer4215010828-32 x 1/2" Slotted Head Machine Screw	32	120766	1	End Section
35 120758 2 Feed Through Terminal Block 36 120761 1 Four Position Feed Through Terminal Block 37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	33	120750	1	Ground Terminal Block
361207611Four Position Feed Through Terminal Block371207585Feed Through Terminal Block381207612Four Position Feed Through Terminal Block391207651Standard End Stop403330021Sprinkler Mounting Bracket411530002#8 Flat Washer4215010828-32 x 1/2" Slotted Head Machine Screw	34	120761	1	Four Position Feed Through Terminal Block
37 120758 5 Feed Through Terminal Block 38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	35	120758	2	
38 120761 2 Four Position Feed Through Terminal Block 39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw	36	120761	1	Four Position Feed Through Terminal Block
39 120765 1 Standard End Stop 40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw		120758		
40 333002 1 Sprinkler Mounting Bracket 41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw				
41 153000 2 #8 Flat Washer 42 150108 2 8-32 x 1/2" Slotted Head Machine Screw		120765	1	-
42 150108 2 8-32 x 1/2" Slotted Head Machine Screw		333002	1	
43 881039 1 C°/F° Digital Temperature Controller				
	43	881039	1	C°/F° Digital Temperature Controller




Illus. No.	Part No.	<u>Qty</u>	<u>Description</u>
1	334611	1	Right Hand Electrical Panel ONLY
2	121429	28	2" Deep x 1" Wide Wireway*
3	121422	28	1" Wireway Cover*
4	121429	8	2" Deep x 1" Wide Wireway*
5	121422	8	1" Wireway Cover*
6	121429	12	2" Deep x 1" Wide Wireway*
7	121422	12	1" Wireway Cover*
8	121429	12	2" Deep x 1" Wide Wireway*
9	121422	12	1" Wireway Cover*
10	121429	12	2" Deep x 1" Wide Wireway*
11	121422	12	1" Wireway Cover*
12	121429	31	2" Deep x 1" Wide Wireway*
13	121422	31	1" Wireway Cover*

^{*} Sold by the inch

Telephone: (508) 678-9010 Fax: (508) 678-9447

For models mfd. as of August 26, 1997

MAN3757




For models mfd. as of August 26, 1997

Illus. No.	Part No.	<u>Qty</u>	Description
1*	132444	1	3HP 110V Control Relay
2	120721	3	Fused Disconnect Terminal Block (for 380, 460, 575V ONLY)
		4	Fused Disconnect Terminal Block (for 2808, 240V ONLY)
3	120997	1	20 Amp Fused Disconnect Terminal Block
4	120999	4	Blank Marking Tag (for 380, 460, 575V ONLY)
	120999	5	Blank Marking Tag (for 208, 240V ONLY)
5	136031	2	7 Amp Fast Acting Fuse (for 208 volt models)
	182453	2	6 Amp Fast Acting Fuse (for 230/240 volt models)
6	136056	1	20 Amp Slo-Blo Fuse (for 208/230/240 volt models)
7	136057	2	0.5 Amp Slo-Blo Fuse (for 208/230/240 volt models)
8	136056	1	20 Amp Slo-Blo Fuse (for 380/416/460/575 volt models)
9	136057	1	0.5 Amp Slo-Blo Fuse (for 380/416/460/575 volt models)
10	182453	2	6 Amp Fast Acting Fuse (for 380/416 volt models)
	136030	2	5 Amp Fast Acting Fuse (for 460/480 volt models)
	136052	2	4 Amp Fast Acting Fuse (for 575/600 volt models)
11	120761	2	Four Position Terminal Block
12	120752	2	Disconnect Block
13	120998	6	Bus Bar Screw
14	120990	3	2 Pole Bus Bar
15	120750	1	Ground Terminal Block
16	120766	1	End Plate
17	120752	2	Disconnect Block
18	120766	1	End Plate
19	120752	2	Disconnect Block
20	120766	1	End Plate
21	120750	2	Ground Terminal Block
22	150309	4	10-16 x 1/2" Hex Head Crimptite Screw
23	120765	1	End Stop
24	120768	-	DIN Mounting Rail (Sold by the inch)
25	150108	4	8-32 x 1/2" Phillips Crimptite Screw
26	153000	4	#8 Flat Washer
27	152005	4	3/8-16 Hex Nut
28	153005	4	3/8" Lock Washer
29	153004	4	3/8" Flat Washer
30	132087	1	Control Transformer 300VA (for 208/240 volt models)
	132088	1	Control Transformer 450VA (for 380/416 volt models)
2.1	132089	1	Control Transformer 450VA (for 460/480/575 volt models)
31	150106	2	8-32 x 1" Phillips Head Machine Screw
32	120730	1	30 Position A, B, C Block
33	123223	1	Mini Flasher, 24 VAC
34	153000	1	#8 Flat Washer
35 36	131408	9	DPDT Socket
36 37	150103	9	8-32 x 3/4" Phillips Head Machine Screw
37	131407	9	DPDT Relay
38	131409	9	Hold Down

^{*} For models with sprinkler option

For models mfd. prior to August 26, 1997

MAN2864




Illus. No.	Part No.	<u>Qty</u>	Description
1	120765	1	End Stop
2	120721	4	Fused Disconnect Terminal Block (for 380, 460, 575 volts ONLY)
		5	Fused Disconnect Terminal Block (for 208, 240 volts ONLY)
3	120999	4	Blank Marking Tag (for 380, 460, 575 volts ONLY)
	120999	5	Blank Marking Tag (for 208, 240 volts ONLY)
4*		1	Fuse (for 208, 240 volts ONLY)
5*		1	Fuse (for 208, 240 volts ONLY)
6*		1	Fuse (for 208, 240 volts ONLY)
7*		1	Fuse (for 208, 240 volts ONLY)
8*		1	Fuse (for 208, 240 volts ONLY)

For models mfd. prior to August 26, 1997

Illus. No.	Part No.	<u>Qty</u>	Description
9*		1	Fuse (for 380 volts ONLY)
		1	Fuse (for 480 volts ONLY)
		1	Fuse (for 575 volts ONLY)
10*		1	Fuse (for 380 volts ONLY)
		1	Fuse (for 480 volts ONLY)
		1	Fuse (for 575 volts ONLY)
11*		1	Fuse (for 380, 460, 575 volts ONLY)
12*		1	Fuse (for 380, 460, 575 volts ONLY)
13	120761	2	Four Position Terminal Block
14	120752	2	Disconnect Block
15	120998	6	Bus Bar Screw
16	120990	3	2 Pole Bus Bar
17	120750	1	Ground Terminal Block
18	120766	1	End Plate
19	120752	2	Disconnect Block
20	120766	1	End Plate
21	120752	2	Disconnect Block
22	120766	1	End Plate
23	120750	2	Ground Terminal Block
24	150309	4	10-16 x 1/2" Hex Head Crimptite Screw
25	120768	-	DIN Mounting Rail (Sold by the inch)
26	150108	4	8-32 x 1/2" Phillips Crimptite Screw
27	153000	4	#8 Flat Washer
28	152005	4	3/8-16 Hex Nut
29	153005	4	3/8" Lock Washer
30	153004	4	3/8" Flat Washer
31*	881854	1	208V 300VA Control Transformer Kit
	881855	1	240V 300VA Control Transformer Kit
	881856	1	380/416V 450VA Control Transformer Kit
	881857	1	460/480V 450VA Control Transformer Kit
32	150106	2	8-32 x 1" Phillips Head Machine Screw
33	120730	1	30 Position A, B, C Block
34	123223	1	Mini Flasher, 24 VAC
35	153000	1	#8 Flat Washer
36	131408	9	DPDT Socket
37	150103	9	8-32 x 3/4" Phillips Head Machine Screw
38	131407	9	DPDT Relay
39	131409	9	Hold Down
40**	132444	1	3HP 110V Control Relay


^{*} Control Transformer Kits include new fuses. Fuses **cannot** be ordered separate.

^{**}For models with sprinkler option.



Illus. No.	Part No.	Qty	Description
1	120768	_	DIN Mounting Rail (Sold by the inch)
2	120765	1	End Stop
3	150309	4	10-16 x 1/2" Hex Head Crimptite Screw
4	137913	1	Micro One Expansion Computer
5	137914	1	Computer Interface Cable
6*	881029	1	Micro One Computer (Programmed)
7	120765	1	End Stop
8	120768	_	DIN Mounting Rail (Sold by the inch)
9	150309	4	10-16 x 1/2" Hex Head Crimptite Screw
10	120765	1	End Stop
11	120766	1	End Plate
12	120758	9	Single Input Block
13	120761	1	Four Position Block
14	120758	4	Single Input Block
15	120761	1	Four Position Block
16	120758	14	Single Input Block
17	120761	2	Four Position Block
18	120758	13	Single Input Block
19	120761	3	Four Position Block
20	120758	3	Single Input Block
21	120999	16	Blank Marking Tag
22	120761	4	Four Position Block
23	120765	1	End Stop
24	120766	1	End Plate
25	120758	5	Single Input Block
26	120761	3	Four Position Block
27	120750	1	Ground Terminal Block
28	120758	3	Single Input Block
29	120750	1	Ground Terminal Block
30	120758	6	Single Input Block
31	120765	1	End Stop
32	150309	4	10-16 x 1/2" Hex Head Crimptite Screw
33	120765	1	End Stop
34	120768	-	Din Mounting Rail (Sold by the inch)
35	131408	3	DPDT Socket
36	150103	4	8-32 x 3/4" Phillips Head Machine Screw
37	131407	3	DPDT Relay
38	131409	3	Hold Down


^{*} Dryer serial number **must be** provided.




<u>Illus. No.</u>	Part No.	<u>Qty</u>	Description
1	153004	4	3/8" Flat Washer
2	153005	4	3/8" Lock Washer
3	152005	4	3/8-16 Hex Nut
4	120768	-	Din Mounting Rail (Sold by the inch)
5	131956	1	56-80 Amp Manual Starter (Blower Motor)
			(for 208/230 volt models)
	131957	1	25-40 Amp Manual Starter (Blower Motor)
			(for 380/416/460/575 volt models)

Illus. No.	Part No.	<u>Qty</u>	Description
6	132384	1	Auxiliary Contact Block
7	150300	3	#10 x 1/2" Hex Washer TEK Screw
8	120765	1	End Stop
9	131957	1	25-40 Amp Manual Starter (Drive Motor)
-			(for 208 volt models)
	131969	1	20-25 Amp Manual Starter (Drive Motor) (for 230 volt models)
	131970	1	9-14 Amp Manual Starter (Drive Motor)
			(for 380/416/460 volt models)
	131962	1	6-10 Amp Manual Starter (Drive Motor) (for 575 volt models)
10	132384	1	Auxiliary Contact Block
10	132304	1	(for 208 volt models)
	132389	1	Auxiliary Contact Block
	132307	1	(for 230/380/416/460/575 volt models)
11*	136052	2	4 Amp Fuse
12	136032	2	8 Amp Fast-Acting Fuse
13	120724	2or4	Blank Marking Tags
14	120721	2	Fused Disconnect Terminal Block
15*	120721	2	Fused Disconnect Terminal Block
16	132423	1	Reversing Contactor
10	102120	1	(for 208/230 volt models)
	132424	1	Reversing Contactor
			(for 380/416/460/575 volt models)
17	132437	2	24-48 Volt Varistor
18	132485	1	24 Volt Spike Suppressor
19	132479	1	Blower Contactor
			(for 208/230 volt models)
	132481	1	Blower Contactor
			(for 380/416/460/575 volt models)
20	122424	1	Small Power Warning Label
21	120768	_	DIN Mounting Rail (sold by the inch)
22	150300	5	#10 x 1/2" Hex Head TEK Screw
23	120763	1	End Holder
24	120762	3	Terminal Block
25	120763	1	End Holder
26	120750	1	Ground Terminal Block
27*	120758	2	Feed Thru Terminal Block
28*	120750	1	Ground Terminal Block
29	112075	1	"Ground Here" Label
30	152002	1	1/4-20 Hex Nut
31	153007	1	1/4" Lock Washer
32	121012	2	Terminal Lug

For models mfd. as of November 14, 1997



Illus. No.	Part No.	<u>Qty</u>	Description
1	101152	1	SH x 1-3/8" Bushing
2	101187	1	2B x 3.6 Sheave (60 Hz Models)
	101195	1	2B x 4.4 Sheave (50 Hz Models)
3	100143	2	A 29 Belt
4	100704	1	1/4" x 1/4" x 1-3/4" Key
5	181023	1	7-1/2 HP 50/60 Hz Drive Motor
6	153004	4	3/8" Flat Washer
7	153005	4	3/8" Lock Washer
8	150508	4	3/8-16 x 3/4" Hex Head Bolt




1 814	066 1	Motor Adjustment Plate ONLY	
	595 2	Motor Threaded Block	
	609 2	1/2-13 x 4-1/2" Long Hex Head Bolt	
4 814	065 2	Motor Adjustment Bracket	
5 153	026 2	1/2" Lock Washer	
6 152	011 2	1/2-13 Hex Nut	
7 153	005 4	3/8" Lock Washer	
8 150	617 4	3/8-16 x 1" Long Hex Head Bolt	
9 101	299 1	Double Sprocket	
10 101	212 1	Bushing 1-5/8" Dia. Bore	
11 181	017 1	7-1/2 HP, 1200 RPM Motor	
12 153	026 4	1/2" Lock Washer	
13 150	633 4	1/2-13 x 2-1/4" Long Hex Head Bolt	


Telephone: (508) 678-9010

Fax: (508) 678-9447

For models mfd. as of November 14, 1997




<u>Illus. No.</u>	Part No.	<u>Qty</u>	Description
1	820600	2	Drive Wheel Assembly
2	101191	2	RI x 2" Taper Lock Bushing
3	100234	2	2" Pillow Block Bearing
4	153016	4	5/8" Flat Washer
5	150627	4	5/8-11 x 5" Hex Head Bolt
6	101022	1	2" Taper Bushing for Speed Reducer
7	153016	4	5/8" Flat Washer
8	153015	4	5/8" Lock Washer
9	152010	4	5/8-11 Hex Nut
10	101019	1	Taper Bushed Speed Reducer
11	101176	1	2B x 5.6 Sheave
12	100709	1	3/8" x 3/8" x 2" Key
13	101196	1	SDS x 1-5/8" Bushing
14	331548	1	2" x 64-11/16" Drive Shaft
15	150629	2	1/2-13 x 3-1/2" Hex Head Bolt
16	153026	2	1/2" Lock Washer
17	152011	2	1/2-13 Hex Nut



Illus. No.	Part No.	Qty	Description
1	101191	2	Wheel Taper Lock Bushing
2	820600	2	Drive Wheel Assembly with Hub
3	100712	1	1/2" x 1/2" x 3" Long Key
4	100234	2	Pillow Block Bearing
5	150627	4	5/8-11 x 5" Long Bolt
6	153016	4	5/8" Flat Washer
7	153016	4	5/8" Flat Washer
8	153015	4	5/8" Lock Washer
9	152010	4	5/8-11 Hex Nut
10	334577	1	Drive Shaft
11	100712	1	1/2" x 1/2" x 3" Long Key
12	100712	1	1/2" x 1/2" x 3" Long Key
13	101210	1	Bushing
14	101297	1	Sprocket
15	150629	2	1/2-13 x 3-1/2" Long Full Thread Bolt
16	153026	2	1/2" Lock Washer
17	152011	2	1/2-13 Hex Nut


Telephone: (508) 678-9010

Fax: (508) 678-9447




Illus. No.	Part No.	<u>Qty</u>	Description
1	152011	4	1/2-13 Hex Nut
2	153026	4	1/2" Lock Washer
3	153011	4	1/2" Flat Washer
4	150606	4	1/2-13 x 2" Long Hex Head Bolt
5	153026	4	1/2" Lock Washer
6	153011	4	1/2" Flat Washer
7	150606	4	1/2-13 x 2" Long Hex Head Bolt
8	153026	4	1/2" Lock Washer
9	153011	4	1/2" Flat Washer
10	814067	1	Idler Mount ONLY
11	152011	2	1/2-13 Hex Nut
12	153026	2	1/2" Lock Washer
13	150609	2	1/2-13 x 4-1/2" Long Hex Head Bolt
14	101211	1	Bushing 1-3/4" Dia. Bore
15	101298	1	Sprocket
16	100710	1	3/8" x 3/8" x 3" Long Key
17	334597	2	Bearing Spacer Block
18	100239	2	1-3/4" Dia. Pillow Block Bearing
19	100816	2	1-3/4" E-Clip
20	153011	4	1/2" Flat Washer
21	150629	4	1/2-13 x 3-1/2" Long Hex Head Bolt
22	154322	4	3/8-24 x 7/16" Long Set Screw
23	334598	1	Speed Reducing Idler Shaft
24	100710	1	3/8" x 3/8" x 3" Long Key
25	101296	1	Sprocket
26	101154	1	Bushing


Telephone: (508) 678-9010 Fax: (508) 678-9447




Illus. No.	Part No.	<u>Qty</u>	Description
1	881399	1	Tumbler
2	820600	2	Drive Wheel Assembly
3	101191	2	Wheel Taper Lock Bushing
4	170511	2	1/8-27 N.P.T. Grease Fitting
5	150627	4	5/8-11 x 5" Long Bolt
6	153016	4	5/8" Flat Washer
7	880882	2	" Pillow Block Bearing
8	152011	2	1/2-13 Hex Nut
9	153026	2	1/2" Lock Washer
10	150629	2	1/2-13 x 3-1/2" Long Full Thread Bolt
11	153016	4	5/8" Flat Washer
12	153015	4	5/8" Lock Washer
13	152010	4	5/8-11 Hex Nut
14	334578	1	Idler Shaft
15	100712	2	1/2" x 1/2" x 3" Long Key




Illus. No.	Part No.	<u>Qty</u>	<u>Description</u>
1	102102	1	Tumbler Sensor Magnet
2	154200	1	5/32" Pop Rivet
3	332750	1	Rotational Sensor Mounting Bracket
4	881383	1	Rotational Sensor Assembly
5	881384	1	Rotational Sensor Harness




Illus. No.	Part No.	<u>Qty</u>	Description				
1	152053	2	3/4-16 Left Hand Jam Nut				
2	153071	1	2-3/4" O.D. Fan Washer				
3	100661	1	22-1/4" Dia. Blower Wheel				
4	100710	1	3/8" x 3/8" x 3" Long Key				
5	334445	1	Shaft				
6	814005	1	otor Mount ONLY				
7	153004	6	3/8" Flat Washer				
8	153005	6	3/8" Lock Washer				
9	150617	6	3/8-16 x 1" Long Hex Head Bolt				
10	100239	2	1-3/4" Dia. Bearing				
11	150606	4	1/2-13 x 2" Long Hex Head Bolt				
12	153026	4	1/2" Lock Washer				
13	153011	4	1/2" Flat Washer				
14	116014	1	Felt Seal				
15	100710	1	3/8" x 3/8" x 3" Long Key				
16	100172	2	BX-66 V-Belt (Gas Models ONLY)				
	100179	2	BX-75 V-Belt (Steam Models ONLY)				
17	101165	1	2B 18.4 Pulley				
18	101154	1	SK x 1-3/4 Bushing Models				
19	101196	1	SDS x 1-5/8 Bushing				
20	101202	1	2B 5.2 Pulley (60 Hz Gas Models ONLY)				
	101185	1	2B 6.2 Pulley (50 Hz Gas Models ONLY)				
	101175	1	2B 6.8 Pulley (Steam Models ONLY)				
21	152011	4	1/2-13 Hex Nut				
22	153011	4	1/2" Flat Washer				
23	181006	1	25 HP 3600 RPM Motor				
24	150606	4	1/2-13 x 2" Long Hex Bolt				
25	153026	4	1/2" Lock Washer				
26	154322	4	3/8-24 x 7/16" Long Set Screw				
27	814074	1	Fan Motor Adjustment Angle				
28	152011	4	1/2-13 Hex Nut				
29	334635	1	Fan Motor Adjustment Block				
30	153026	2	1/2" Lock Washer				
31	150630	2	1/2-13 x 6" Hex Head Bolt				
32	150618	2	1/2-13 x 1" Hex Head Bolt				
33	100816	2	1-3/4" Dia. Retaining Clip (Used on models mfd. prior to 11-18-96)				




Illus. No.	Part No.	<u>Qty</u>	Description
1	814008	1	Sensor Bracket Assembly
	814009	1	Sensor Bracket Assembly Complete
			(includes illus. nos. 1 through 10)
2	150000	2	#6-32 x 1/4" Slotted Round Head Machine Screw
3	153010	2	#6 Star Washer
4	130112	1	L-225 Thermostat
5	152000	3	#6-32 Hex Nut
6	121028	2	1/4" x .032 Insulated Terminal
7	122701	4	Sockets
8	122605	1	4 Pin Socket Connector (Female)
9	154007	2	1/4" Push-On Fastener
10	880251	1	1/4" Temperature Sensor Probe Assembly
			(includes illus. nos. 6 through 10)
11	150301	4	#8-18 x 7/16" Phillips Pan Head TEK Screw




Illus. No.	Part No.	<u>Qty</u>	Description
1	880815	1	DSI Module 50/60 Hz
2	820100	1	DSI Module Mount Assembly ONLY
3	121400	2	Universal Bushing
4	150522	3	1/4-20 x 1/2" Self Tapping Hex Head Machine Screw
5	150301	1	#8-18 x 7/16" Phillips Pan Head TEK Screw
6	153010	4	#6 Star Washer
7	152000	4	#6-32 Hex Nut




Illus. No.	Part No.	<u>Qty</u>	Description
1	150301	4	#8-18 x 7/16" Phillips Pan Head TEK Screw
2	334086	1	Manifold Rest
3	141110	5	Burner Tube
4	150301	10	#8-18 x 7/16" Phillips Pan Head TEK Screw
5	150301	4	#8-18 x 7/16" Phillips Pan Head TEK Screw
6	334083	1	Front Burner Tube Rest
7	150301	5	#8-18 x 7/16" Phillips Pan Head TEK Screw
8	150301	5	#8-18 x 7/16" Phillips Pan Head TEK Screw
9	331290	1	Sight Hole Disk
10	332597	1	Burner Box Cover Plate
11		1	Sail Switch Assembly See Page: 44
12	150309	2	#10-16 x 1/2" Hex Head Crimptite Screw
13	880325	1	Ignitor/Flame Probe Assembly Kit
14	150001	2	#6-32 x 1/2" Round Head Machine Screw
15	130401	1	L-330 Hi-Limit
16	151000	2	#6-32 Pal Nut
17	881395	1	Front Burner Box ONLY
18	881144	1	Hi-Limit Mounting Bracket
19	150301	4	#8-18 x 7/16 Phillips Pan Head TEK Screw
20	332826	1	Burner Baffle
21	150301	4	#8-18 x 7/16" Phillips Pan Head TEK Screw



Illus. No.	Part No.	<u>Qty</u>	<u>Description</u>
1	150301	4	#8-18 x 7/16" Phillips Pan Head TEK Screw
2	334086	1	Manifold Rest
3	141110	5	Burner Tube
4	150301	10	#8-18 x 7/16" Phillips Pan Head TEK Screw
5	150301	4	#8-18 x 7/16" Phillips Pan Head TEK Screw
6	334084	1	Rear Burner Tube Rest
7	150301	5	#8-18 x 7/16" Phillips Pan Head TEK Screw
8	150301	1	#8-18 x 7/16" Phillips Pan Head TEK Screw
9	331290	1	Sight Hole Disk
10	332597	1	Burner Box Cover Plate
11		1	Sail Switch Assembly See Page: 44
12	150309	2	#10-16 x 1/2" Hex Head Crimptite Screw
13	880325	1	Ignitor/Flame Probe Assembly Kit
14	150001	2	#6-32 x 1/2" Round Head Machine Screw
15	130401	1	L-330 Hi-Limit
16	151000	2	#6-32 Pal Nut
17	881394	1	Rear Burner Box ONLY
18	881144	1	Hi-Limit Mounting Bracket
19	150301	4	#8-18 x 7/16 Phillips Pan Head TEK Screw
20	332826	1	Burner Baffle
21	150301	4	#8-18 x 7/16" Phillips Pan Head TEK Screw




Illus. No.	Part No.	Qty	Description
1	105500	1	Sail Switch Actuator Rod
2	332689	1	Sail Switch Damper
3	154002	1	1/8" Push On Fastener
4	802800	1	Sail Switch Box with Cover and Bracket ONLY (items 4, 8, and 9)
	881376	1	Sail Switch Box Assembly Complete
			(includes illus. nos. 1 through 4 and 6 through 10)
5	150300	2	#10 x 1/2" Hex Washer Head TEK Screw
6	150303	2	#4 x 3/4" Pan Head Machine Screw
7	122404	1	Sail Switch
8	802799	1	Sail Switch Box Cover and Bracket ONLY
9	150309	2	#10-16 x 1/2" Hex Head Crimptite Screw
10	154004	1	Twin Speed Nut



Illus. No.	Part No.	<u>Qty</u>	Description
1	332531	2	Air Jet Mounting Plate
2	153007	4	1/4" Lock Washer
3	152002	4	1/4-20 Hex Nut
4	143277	2	1/4" Comp. x 1/8" M.P.T. Connector
5	143100	3	1/4" Aluminum Tubing (Sold by the foot)
6	143100	1	1/4" Comp. Union Tee
7	143259	2	Bulkhead Fitting, 1/4" Comp. x 1/8" F.P.T.
8	143239	1	1/4" Comp. x 1/8" M.P.T. 90 Degree Brass Elbow
9	150309	2	10-16 x 1/2" Hex Head Crimptite Screw
10	100520	1	1/8" Muffler
11	150002	2	#6-32 x 1" Phillips Round Head Machine Screw
12	100498	1	3 Way Valve
13	100478	1	1/4" Poly x 1/8" M.P.T. Connector
14	153010	2	#6 Star Washer
15	152000	2	#6-32 Hex Nut
13	132000		110-32 110A 11ut


Fax: (508) 678-9447



<u>Illus. No.</u>	Part No.	<u>Qty</u>	Description
1	142931	1	2" x 1-1/2" Double Tapped Bushing
2	150504	4	5/16-18 x 1" Long Hex Nut
3	142514	1	2" Floor Flange
4	153002	4	5/16" Lock Washer
5	152004	4	5/16-18 Hex Nut
6	142569	1	1-1/2" x 18" Long Nipple
7	142611	1	1-1/2" x 1-1/4" x 1-1/4" Tee
8	142725	1	1-1/4" x 2" Long Nipple
9	142725	1	1-1/4" x 2" Long Nipple
10	142554	1	1-1/4" x 90° Elbow
11	142725	1	1-1/4" x 2" Long Nipple
12	141416	2	1-1/4" x 48" Flex Hose
13	142558	1	1-1/4" Union
14	142558	1	1-1/4" Union
15	142554	1	1-1/4" x 90° Elbow
16	142725	1	1-1/4" x 2" Long Elbow
17	142611	1	1-1/2" x 1-1/4" x 1-1/4" Tee
18	142573	1	1-1/2" x 10" Long Nipple
19	142512	1	1-1/2" x 90° Elbow
20	142736	1	1-1/2" x 20" Long Nipple
21	142512	1	1-1/2" x 90° Elbow
22	142596	1	1-1/2" x 5" Long Nipple
23	142603	1	1-1/2" Union
24	150522	4	TEK Screw
25	814063	1	Gas Pipe Bracket
26	142596	1	1-1/2" x 5" Long Nipple
27	142915	1	1-1/2" x 45° Elbow
28	142738	1	1-1/2" x 2" Long Nipple
29	142915	1	1-1/2" x 45° Elbow
30	150510	8	1/4-20 x 3/4" Long Hex Head Bolt
31	153007	8	1/4" Lock Washer
32	142736	1	1-1/2" x 20" Long Nipple
33	142512	1	1-1/2" x 90° Elbow
34	334602	4	Bottom Gas Pipe Bracket
35	142736	1	1-1/2" x 20" Long Nipple
36	142512	1	1-1/2" x 90° Elbow
37	332828	1	Pipe Bracket
38	150522	2	TEL Screw
39	154351	6	1-1/2" Pipe U-Bolt
40	142808	1	1" x 3" Long Nipple
41	142603	1	1-1/2" Union
42	142573	1	1-1/2" x 10" Long Nipple
43	142841	1	1-1/4" x 1-1/4" x 1-1/2" Tee
44	142599	2	1-1/4" x 22" Long Nipple
45	142558	2	1-1/4" Union
46	142725	2	1-1/4" x 2" Long Nipple


Continued on next page.

Illus. No.	Part No.	<u>Qty</u>	Description
47	142554	2	1-1/4" x 90° Elbow
48	142575	2	1-1/4" x 18" Long Nipple
49	142728	2	1" to 1-1/4" Reducing Elbow
50	142844	2	1" x 45° Male Elbow
51	141302	2	1" Shut-Off
52	142808	2	1" x 3" Long Nipple
53	142602	2	1" Union
54	142711	2	1" Close Nipple
55	140017	2	1" 24V Gas Valve (Natural Gas)
	140018	2	L.P. Gas Valve Conversion Kit
56	142724	2	1" x 2" Long Nipple
57	142548	2	1" x 90° Elbow
58	141242	1	Rear Manifold, 5 Port
59	141241	1	Front Manifold, 5 Port
60	140840	10	#1 Burner Orifice (natural gas) ONLY
	140821	10	#28 Burner Orifice (liquid propane gas) ONLY
	881425	1	ADG-410 L.P. Conversion Kit




Illus. No.	Part No.	<u>Qty</u>	Description
1	881252	1	Tilt Switch Assembly Complete (includes illus. nos. 1, 2, and 4)
	122365	1	Limit Switch Rotary Head ONLY
2	122369	1	Tilt Switch Arm
3	150211	4	10-32 x 2" Phillips Pan Head Machine Screw
4	122367	1	Tilt Switch Body
5	153009	4	#10 Star Washer
6	152008	4	#10-32 Hex Nut
7	150309	4	#10-16 x 1/2" Hex Head Crimptite Screw
8	332794	1	Tilt Switch Bracket

NOTE: One assembly for one-way tilt models. Two assemblies for two-way tilt models.



Illus. No.	Part No.	<u>Qty</u>	Description
1	100562	1	Piston (5" Bore, 15" Stroke)
2	143283	1	3/8" Poly x 3/8" M.P.T. Straight Connector
3	143221	1	3/8" Poly Tee, Brass
4	143120	20	3/8" Poly Tubing (Sold by the foot)
5	143213	1	3/8" Poly x 3/8" M.P.T. Elbow, Brass
6	334309	2	Cylinder Pin Nylon Bumper
7	150435	4	3/8-16 x 3" Socket Head Cap Screw
8	100553	1	Rod Eye
9	154315	2	1/2-20 x 1-1/8" Socket Head Set Screw
10	331543	1	1" Dia. Pin
11	150599	4	1/4-20 x 1-1/4" Hex Head Machine Bolt
12	153026	4	1/2" Lock Washer
13	153011	4	9/16" I.D. Flat Washer
14	881170	1	Clevis Assembly

51




<u>Illus. No.</u>	Part No.	<u>Qty</u>	Description
1	100487	1	3/4" Diameter Pin with Cotter Pin
1	100487	1	3/4 Diameter Pin with Cotter Pin
2	881529	1	Post Assembly
3	100553	1	Rod Eye
4	154315	2	1/4-20 x 1" Socket Head Set Screw
5	334309	2	Nylon Bumper
6	150435	4	3/8-16 x 3" Socket Head Cap Screw
7	331543	1	1" Diameter Pin
8	150599	4	1/2-20 x 1-1/8" Hex Head Bolt
9	153026	4	1/2" Lock Washer
10	881170	1	Clevis Assembly

Telephone: (508) 678-9010

Post Assembly


Fax: (508) 678-9447

For 1 Automatic Door



Illus. No.	Part No.	<u>Qty</u>	Description
1	152000	2	#6-32 Hex Nut
2	153010	2	#6 Star Washer
3	330987	1	Valve Mounting Bracket
4	150522	2	1/4-20 x 1/2" Hex Head TEK Screw
5	143289	1	1/4" Poly x 1/8" M.P.T. Connector
6	100498	1	3 Way Valve
7	150002	2	#6-32 x 1" Phillips Round Head Machine Screw
8	100520	1	1/8" Muffler
9	143239	1	1/8" 2-1/2" Brass Nipple
10	100520	1	1/8" Muffler
11	100468	1	4 Way Valve, 24 Volt
12	143289	2	1/4" Poly x 1/8" M.P.T. Connector
13	143115	38	1/4" Poly Flo Tubing (sold by the foot)
14	150008	2	#6-32 x 1-1/4" Right Hand Machine Screw
15	814349	1	AD-410 Solenoid Interface Junction Box
16	120703	1	6 Position Screw Connector
17	152000	2	#6-32 Hex Nut
18	120915	2	1/2" N.P.T. Lock Nut
19	120914	2	1/2" N.P.T. Metal Clad Sealing Washer
20	120656	1	Straight Brown Cord Grip Connector
21	120653	1	Straight White Cord Grip Connector


For 2 Automatic Doors



Illus. No.	Part No.	<u>Qty</u>	Description
	142117		1/4/ D.1 El (C.111 (1.6.))
1	143115	-	1/4" Poly Flow Tubing (Sold by the foot)
2	143289	2	1/4" Poly x 1/8" MPT Connector
3	100468	1	4-Way Value 24 Volt
4	100520	1	1/8" Muffler
5	143268	1	1/8" Brass Street Elbow
6	143238	1	1/8" Close Nipple
7	100520	1	1/8" Muffler
8	143268	1	1/8" Brass Street Elbow
9	143238	1	1/8" Close Nipple
10	143237	1	1/8" Brass Cross
11	143238	1	1/8" Close Nipple
12	143250	1	1/8" Brass Plug
13	100468	1	4-Way Valve 24 Volt
14	143289	2	1/4" Poly x 1/8" MPT Connector
15	143115	-	1/4" Poly Flow Tubing (Sold by the foot)
16	150002	2	#6-32 x 1" Phillips Round Head Machine Screw
17	100520	1	1/8" Muffler
18	100498	1	3-Way Valve 24 Volt
19	143115	-	1/4" Poly Flow Tubing
20	143289	1	1/4" Poly x 1/8" MPT Connector
21	150522	2	1/4-20 x 1/2" Hex Head TEK Screw
22	330987	1	Valve Mounting Bracket
23	153010	2	#6 Star Washer
24	152000	2	#6-32 Hex Nut

Fax: (508) 678-9447


For One-Way Tilt Models



For One-Way Tilt Models


Illus. No.	Part No.	<u>Qty</u>	Description
1	814011	1	Pneumatic Plate ONLY
2	100479	1	3/8" Filter/Regulator Gauge
			(for models mfd. as of July 14, 1997)
	100516	1	Filter/Regulator/Lubricator Gauge
			(for models mfd. prior to July 14, 1997)
3	150512	4	1/4-20 x 1/2" Hex Head Bolt
4	153007	6	1/4" Lock Washer
5	100558	1	5 Port, 3 Position, 24 VAC Tilting Solenoid
6	100462	2	3/8" Muffler
7	143283	5	3/8" Poly x 3/8" MPT Straight Connector
8	143120	-	3/8" Poly Flo Tubing (Sold by the foot)
9	143241	1	3/8" Close Nipple
10	143206	2	3/8" Flow Control
11	153018	4	1/4" Flat Washer
12	143115	-	1/4" Poly Flo Tubing (Sold by the foot)
13	143290	1	1/4" Poly x 3/8" MPT Brass Elbow
14	150524	2	1/4-20 x 2" Hex Head Bolt
15	150522	6	1/4-20 x 1/2" Hex Head TEK Screw
16	143213	4	3/8" Poly x 3/8" MPT Brass Elbow
17	332841	1	Air Flow Valve Plate
18	143220	1	3/8" Brass Tee
19	332624	1	Filter/Regulator Adapter Bracket

For Two-Way Tilt Models




For Two-Way Tilt Models


<u>Illus. No.</u>	Part No.	<u>Qty</u>	Description
1	814011	1	Pneumatic Plate ONLY
2	100479	1	3/8" Filter/Regulator Gauge
			(for models mfd. as of July 14, 1997)
	100516	1	Filter/Regulator/Lubricator Gauge
			(for models mfd. prior to July 14, 1997)
3	150512	6	1/4-20 x 1/2" Hex Head Bolt
4	153007	10	1/4" Lock Washer
5	143220	1	3/8" Brass Tee
6	100558	2	Tilting Solenoid, 24 VAC, 5 Port, 3 Position
	100569	-	24 VAC Coil ONLY
7	100462	4	3/8" Muffler
8	143283	10	3/8" Poly x 3/8" MPT Brass Straight Connector
9	143120	8	3/8" Poly Flo Tubing (Sold by the foot)
10	143241	1	3/8" Close Nipple
11	143206	4	3/8" Flow Control
12	153018	8	1/4" Flat Washer
13	143115	14	1/4" Poly Flo Hi-Temp Tubing (Sold by the foot)
14	143290	1	1/4" Poly x 3/8" MPT Brass Elbow
15	150524	4	1/4-20 x 2" Long Bolt
16	150522	6	1/4-20 x 1/2" Hex Washer Head TEK Screw
17	143157	2	Reducing Poly Tee, 3/8" x 3/8" x 1/4"
18	143221	1	3/8" Poly Tee
19	143213	6	3/8" Poly x 3/8" MPT Brass Elbow
20	332841	2	Air Flow Valve Plate
21	143149	2	1/4" Poly x 1/8" MPT Elbow Connector
22	332624	1	3/8" Filter/Regulator Mounting Bracket
			(for models mfd. as of July 14, 1997)




Illus. No.	Part No.	<u>Qty</u>	Description
1	881426	7	1/4" Hex Plug (1/4" Dia. Hole Drilled Through Center)
2	142926	7	1" x 1/4" Reducing Bushing
3	142548	1	1" x 90° Elbow
4	142579	6	1" x 6" Long Nipple
5	142508	6	1" Tee
6	142724	1	1" x 2" Long Nipple
7	142548	1	1" x 90° Elbow
8	142585	1	1" x 18" Long Nipple
9	142590	1	1" x 45° Elbow
10	142808	1	1" x 3" Long Nipple
11	142590	1	1" x 45° Elbow
12	142746	1	1" x 24" Long Nipple
13	142602	1	1" Union
14	142589	1	1" x 10" Long Nipple
15	142548	1	1" x 90° Elbow
16	142579	1	1" x 6" Long Nipple
17	142548	1	1" x 90° Elbow
18	142587	1	1" x 27-1/2" Long Nipple
19	142602	1	1" Union
20	143136	1	1" Dia. Hose Nipple
21	143210	1	1/4" Comp. x 1/4" MPT Brass Elbow
22	100565	1	1" Water Valve (for models mfd. as of September 9, 1996)
22	881414	1	1" Water Valve (for models mfd. prior to September 9, 1996)
23 24	142808	1	1" x 3" Long Nipple 1" x 90° Elbow
24 25	142548	1	
26	143136 143135	1 1	1" Dia. Hose Nipple 4' Long Flex Hose
27	143133	1	1" x 4-1/2" Long Nipple
28	142548	1	1" x 90° Elbow
29	142808	1	1" x 3" Long Nipple
30	143556	1	1" Ball Valve
31	143100	12	1/4" Aluminum Tubing (Sold by the foot)
32	150415	2	Crimptite Screw
33	814063	1	Lower Sprinkler Bracket
34	154350	6	1" Pipe U-Bolt
35	334255	1	1" Pipe Bracket
36	150522	2	1/4-20 x 1/2" TEK Screw
37	334610	2	Inner Sprinkler Pipe Bracket
38	150522	4	1/4-20 x 1/2" TEK Screw
39	334631	1	Sprinkler Bracket
40	331794	1	Inlet Pipe Bracket
41	143137	2	Hose Clamp
42	150522	2	1/4-20 x 1/2" TEK Screw
43	150522	4	1/4-20 x 1/2" TEK Screw
44	150522	8	1/4-20 x 1/2" TEK Screw




Illus. No.	Part No.	<u>Qty</u>	<u>Description</u>
1	331877	1	Temperature Sensor Mounting Plate
2	150523	2	1/4-20 x 3/4" Hex Head TEK Screw
3	881227	1	RTD Temperature Probe Assembly
			(includes illus. nos. 3, 4, and 8)
4	143296	1	1/4" Compression Fitting
5	120652	1	1/2" NPT Cord Grip (Red)
6	120915	1	1/2" NPT Locknut
7	120914	1	1/4" Metal Clad "O" Ring
8	122736	3	Yellow Ferrule
9	881228	1	Sprinkler Temperature Probe Box Assembly
			(includes illus. nos. 9 and 12)
10	152000	2	6-32 Hex Nut
11	120703	1	6 Position Terminal Block
12	122427	1	Caution Label
13	150008	2	6-32 x 1-1/4" Phillips Head Machine Screw
14	122736	3	Yellow Ferrule
15	120914	1	1/2" Metal Clad "O" Ring
16	120915	1	1/2" NPT Locknut
17	120650	1	90° Cord Grip (White)
18	881229	1	Sprinkler Temperature Probe Harness



Illus. No.	Part No.	<u>Qty</u>	Description
1	165034	1	Steam Coil Assembly
2	150523	8	1/4-20 x 3/4" Hex Head TEK Screw
3	153007	4	1/4" Lock Washer
4	152002	4	1/4-20 Hex Nut
5	820321	2	Steam Damper Hinge Assembly
6	115995	144	Steam Damper Gasket (sold by the inch)
7	881661	1	Steam Damper Assembly
			(includes illus. nos. 6 through 8)
8	102350	2	Steam Damper Foam
9	153007	4	1/4" Lock Washer
10	152002	4	1/4-20 Hex Nut
11	151008	1	5/8-18 S.S. Acorn Nut
12	152030	1	5/8-18 Jam Nut
13	100525	1	2" Bore, 4" Stroke Piston
14	152002	4	1/4-20 Hex Nut
15	153007	4	1/4" Lock Washer
16	100526	1	Piston Pivot Bracket
17	143238	1	1/8" Brass Close Nipple
18	143264	1	1/4" Poly x 1/8" Brass Reducing Bushing
19	100496	1	1/8" Needle Valve
20	100472	1	1/4" Poly x 1/8" MPT Connector
21	143115		1/4" O.D. Tubing (sold by the foot)
22	143156	1	1/4" Poly Tee
23	143115		1/4" O.D. Tubing (sold by the foot)
24	100472	1	1/4" Poly x 1/8" MPT Connector
25	100496	1	1/8" Needle Valve
26	143264	1	1/4" Poly x 1/8" Brass Reducing Bushing
27	143238	1	1/8" Brass Close Nipple
28	100525	1	2" Bore, 4" Stroke Piston
29	151008	1	5/8-18 S.S. Acorn Nut
30	153030	1	5/8-18 Jam Nut
31	152002	4	1/4-20 Hex Nut
32	153007	4	1/4" Lock Washer
33	100526	1	Piston Pivot Bracket
34	152002	2	1/4-20 Hex Nut
35	153007	2	1/4" Lock Washer
36	153010	2	#6 Star Washer
37	152000	2	6-32 Hex Nut
38	330987	1	Micro Valve Support
39	100472	1	1/4" Poly x 1/8" MPT Connector
40	100472	1	1/4" Poly x 1/8" MPT Connector
41	143115		1/4" O.D. Tubing (sold by the foot)
42	100498	1	3-Way Micro Valve - 24 VAC
43	150002	2	6/32 x 1" Phillips Head Machine Screw
44	100520	1	1/8" N.P.T Silencer




Illus. No.	Part No.	Qty	Description
1	100556	1	Sprinkler Solenoid 120 Volt
2	153018	4	1/4" Flat Washer
3	100462	1	3/8" Valve Muffler
4	143283	1	3/8" Poly x 3/8" MPT Brass Connector
5	143120	6	3/8" Poly Flow Tubing (sold by the foot)
6	143151	1	1/4" Compression to 3/8" MPT Brass Elbow
7	153007	2	1/4" Lock Washer
8	150524	2	1/4-20 x 2" Hex Head Machine Bolt
9	143100	12	1/4" Aluminum Tubing (sold by the foot)
10	150309	2	#10-16 x 1/2" Hex Head Crimptite Screw
11	154005	2	1/4" Tube Clip
12	143221	1	3/8" Poly Tee



MAN2793

Illus. No.	Part No.	<u>Qty</u>	Description
1	152005	2	3/8-16 Hex Nut
2	153005	2	3/8" Lock Washer
3	820566	2	Retaining Wheel Assembly
4	153062	4	Spherical Washer
5	153004	2	3/8" Flat Washer
6	150438	2	3/8-16 x 3-1/4" Long Bolt

For Two-Way Tilt Models




Guard Assemblies 67

For Two-Way Tilt Models


Illus. No.	Part No.	<u>Qty</u>	Description
1*	881396	1	Front Guard Door ONLY
2	150300	4	#10 x 1/2" Hex Head TEK Screw
3	170607	1	Door Magnet
4*	881397	1	Front Guard Assembly Complete
			(includes illus. nos. 1 through 6)
5	170348	2	Front Tilt Guard Glide
6	150412	4	3/4" Long Crimptite Screw
7*	334538	1	Side Shield Assembly
8	150512	6	1/4-20 x 1/2" Long Hex Head Bolt
9	153007	6	1/4" Lock Washer
10*	334538	1	Side Shield Assembly
11	150512	6	1/4-20 x 1/2" Long Hex Head Bolt
12	153007	6	1/4" Lock Washer
13	151004	4	1/4-20 Hex Nut
14	153007	6	1/4" Lock Washer
15	821628	2	Spring Catch
16	157014	2	Spring #125
17	108121	2	15" Long Chain
18	154354	2	3/4" Pipe U-Bolt
19*	881398	1	Rear Guard Assembly Complete
			(includes illus. nos. 13 through 21)
20	150412	8	Crimptite Screw, 3/4" Long
21	170345	4	Rear Tilt Nylon Glide

^{*} Specify color when ordering




Illus. No.	Part No.	Qty	Description
1	150522	16	1/4-20 x 1/2" TEK Screw
2*	814032	1	Top Left Panel
3*	814033	1	Bottom Hinged Door Assembly
4	150522	18	1/4-20 x 1/2" TEK Screw
5*	334538	1	Side Shield Assembly
6	150512	6	1/4-20 x 1/2" Long Hex Head Bolt
7	153007	6	1/4" Lock Washer
8*	334600	1	Left Side Rear Base Panel
9	150522	4	1/4-20 x 1/2" TEK Screw
10	150522	10	1/4-20 x 1/2" TEK Screw
11*	814088	1	Left Base Panel Assembly
12	150522	2	1/4-20 x 1/2" TEK Screw
13*	334601	1	Left Side Front Base Panel
14	150522	16	1/4-20 x 1/2" TEK Screw
15*	814031	1	Top Right Panel Assembly (60 Hz ONLY)
16	150522	18	1/4-20 x 1/2" TEK Screw
17*	814033	1	Bottom Hinged Door Assembly
18*	334538	1	Side Shield Assembly
19	153007	6	1/4" Lock Washer
20	150512	6	1/4-20 x 1/2" Long Hex Head Bolt
21	150522	6	1/4-20 x 1/2" Long TEK Screw
22*	334544	1	Right Side Base Panel
23	150522	6	1/4-20x 1/2" Long TEK Screw
24*	334545	1	Gas Inlet Base Panel
25	150522	6	1/4-20 x 1/2" TEK Screw
26*	334544	1	Right Side Base Panel
27	150522	16	1/4-20 x 1/2" Long TEK Screw
28	814031	1	Top Right Panel Assembly (Steam Machines ONLY)

^{*} Specify color when ordering



Illus. No.	Part No.	<u>Qty</u>	Description
1*	334542	2	Piston Cover
2	150415	12	Crimptite Sheet Metal Screw
3*	334671	2	Right Front Base Panel
4	150522	12	1/4-20 x 1/2" TEK Screw
5	332681	2	Right Gusset for Top Front Panel
6	150522	9	1/4-20 x 1/2" TEK Screw
7*	334546	1	Top Front Panel
8*	332680	1	Left Gusset for Top Front Panel
9	150522	7	1/4-20 x 1/2" TEK Screw
10	150522	9	1/4-20 x 1/2" TEK Screw

^{*} Specify color when ordering



Illus. No.	Part No.	<u>Qty</u>	Description		
1	151001	2	#8-32 Pal Nut		
2	150309	4	#10-16 x 1/2" Hex Head Crimptite Screw		
3	150108	2	#8-32 x 1/2" Phillips Head Machine Screw		
4*	821480	1	Cycle Light Bracket (for Steam Models ONLY)		
5	152001	4	#8-32 Hex Nut		
6	153012	4	#8 Star Washer		
7*	332850	1	Cycle Light Bracket (for Gas Models ONLY)		
8	150108	2	#8-32 x 1/2" Phillips Head Machine Screw		
9	123222	1	"Orange" Cycle Light		
10	123221	1	24 VAC Bulb		
11	151001	2	#8-32 Pal Nut		
12	150108	4	#8-32 x 1/2" Phillips Head Machine Screw		

^{*} Specify color when ordering.

88 Currant Road / Fall River, MA 02720-4781

Selector Switch, Nameplate, and Mounting Base Chart

	Models with 2-Way Tilt	Models with Fwd Tilt	Models withFwd Tilt	Models with Rear Tilt
	Manual/Automatic Doors	Manual Doors	Automatic Doors	Manual/Automatic Doors
Illus. No. 13 Selector Switch	ADC Part No. 122348 3-Position Cam Selector Switch	ADC Part No. 122360 2-Position Switch	ADC Part No. 122348 3-Position Cam Selector Switch	ADC Part No. 122348 3-Position Cam Selector Switch
Illus. No. 14	ADC Part No. 122412	ADC Part No. 122422	ADC Part No. 122412	ADC Part No. 122435
Nameplate	"Load-Dry-Unload"	Unload "0-1"	"Load-Dry-Unload"	Load "Level-Off-Tilted"
Illus. No. 37 and Illus. No. 38 Mounting Base	Included with Selector Switch	ADC Part No. 132397 NO-NC Contact Block with Base	Included with Selector Switch	Included with Selector Switch

